





## AQUASOFT VELOURS

Waterborne interior alkyd paint - Velvet

### SURFACE PREPARATION

As stated by DTU 59.1, all surfaces must be clean, dry and free of dirt.  
For new work, all surfaces must be primed with an appropriate primer.  
Old glossy painted surfaces should be sanded or washed with a cleaner and then rinsed with water.  
For deep tones such as yellow or red, apply one coat of primer grey for a better opacity.  
These recommendations do not override a specific description of the substrate.

### APPLICATION

- Application conditions** : DTU 59.1  
**Application equipment** : Brush, Roller, Airless spray-gun.  
**Clean-up solvent** : Water  
**Thinner** : Water  
**Dilution** : Brush (Ready to use), Roller (Ready to use), Airless spray-gun (Ready to use).

### SYSTEM RECOMMENDATIONS

Substrate	Primer coat	Top coat
wood and wood joinery, hydraulic binder-based coating, plasterboard, previously painted surfaces in good condition	Apply 1 coat of PRIM O 2010 or IKARPRIM	Apply 2 coats of AQUASOFT VELOURS
plaster	Apply 1 coat of IKARPRIM or IKARFIX O	

### CONTAINER SIZE

1L - 2.5L - 15L

### SAFETY MEASURES

Refer to the safety Data Sheet